

DMEGC Cloud APP User Manual

www.dmegc-ess.com



01 INSTALLER ACCOUNT REGISTER AND INSTALL NEW SYSTEM

1.1. Register on App


1.1.1. Download and install App

- 1. Android device users can download the "DMEGC" App through major Android -application markets such as Google Play.
- 2. IOS device users can search for "DMEGC" in App Store and download the App.
- 3. QR code download: DMEGC APP can also support scanning QR code with mobile phone for downloading. Please use mobile phone for scanning code.




1.1.2. Register as user account

- 1.If you don't have a user account, please register firstly.
- 2.If you already have a user account, please log in directly.








1



1.1.3. Overview of functions








1.1.4 Create plant and Configure network

After logging in to DMEGC you can create your own power station and monitor the power station operating status and power generation data in real time.





Click "+" to create a plant




Click "Gateway"




Scan QR code of the Wi-Fi Stick

03




Or click
"Manual input" to
input the information

03



Enter plant information



Click
"Distribution network"



Click"Wi-Fi
Network Configuration"





Scan QR code of the Wi-Fi Stick

07










Connect to your Wi-Fi with normal internet access, click "Confirm"



Configured successfully



1. Prerequisites: Wi-Fi and location services must be enabled in advance. Please ensure that the device is powered on. When the device is powered on, the red LED lights around the device must be on.

1.2. Register on cloud


1.2.1. Register as user account

You can create a new account on our web server for the normal monitoring. In addition, a part of our warranty is based on this connection to our web server. The data produced prior to registration can be synchronized to the web server.

Step1: Please use the following steps: Open the portal: dmegc.inteless.com.



Step2: Please fill in "Username", "Password" and click "Log in" if you have already registered.




In this form, all fields with a red star are compulsory, and you can select the finally users or installation procedures.

*Username: Must be an email address / phone number.

*Password: 8-20 digits in length, contain numbers and letters, and at least one capital letter, no spaces, Chinese or special symbols.

More details are available in the Online Monitoring Web Sever Installers User Manual, which can be downloaded from DMEGC homepage.


If not, please register by filling in the following web form:






1.2.2. Create plant


Log in to your account and choose My Plants > "Create plant" to register new system at DMEGC Cloud.






Step 1: Enter SN and Key of Wi-Fi Stick.

Step 2: Enter your plant information.






Step 3: Enter Revenue information.




Step 4: Enter Contact information



Enter the gateway S/N, gateway key, Plant information, Revenue information and Contacts, and click the Complete button. The red* in front of it is required.

7



DMEGC

Hengdian Group DMEGC Magnetics Co., Ltd.

Add.: PV Zone, Xihuan Road, Hengdian, Dongyang City, Zhejiang Province, 310000 P. R. CHINA

Tel.: +86 (0) 571-56260011

E-mail: info-ess@dmegc.com.cn / service@ dmegc.com.cn

Copyright © Hengdian Group DMEGC Magnetics Co., Ltd. All rights reserved.